



- HOME
- ABOUT US
- PRODUCTS
 - DeepRed
 - CoolSilver
 - OverGrey
 - EasyBlue Box
 - DeskPhone
- DOWNLOAD
- VADS WANTED
- SKYPE NEWS
- BUY SKYPEOUT CREDIT
- CALL RATES
- SUPPORT
- CONTACT US

Product Properties Deskphone



- o Supporting Skype and SIP, H.323, MGCP
- o Commercial grade high quality Speakerphone, ideal for conference calls
- o Large LCD with backlight
- o Phone ring for incoming calls, ring style and volume selectable
- o USB1.1 compatible, no external power required
- o Driver and sound card built-in, no driver and sound card required
- o Echo cancellation, noise reduction, full duplex communication
- o Caller ID function of VOIP calls
- o 199 incoming calls and 199 dialed numbers
- o Direct-call button to the partner shop available
- o Keypad: Handfree, Redial, In, Out, Up, Down, Del, Flash, Help
- o PC-to-PC and PC-to-phone operation

buy now

How to use Deskphone with Skype

Download Skype for Windows minimum ver. 1.0.0.106

- o [Download Skype software](#) and install the program
 - Icon means Skype connected successfully;
 - Icon please check your internet connection..

Connect USB-P4K to your computer

- o Plug-in the USB Phone to a free USB-port in your computer, when you see the text "VOIP-Phone" in the LCD window of your phone, phone is correctly connected.

Download CallMe

- o Download [CallMe](#) software and install the program.
- o Start [CallMe](#). Icon on your desktop.
 - After running [CallMe](#), there is a icon on taskbar:
 - Device and Skype are connected successfully;
 - Please run Skype first
 - The P4K connected incorrectly, please reconnect.

Making calls

- o Add "[yamamotogrouplondon](#)" to your **Contacts**.
- o Assign Speed-Dial for it, for example "11".



- Input Number and call out.
Press Digital "1" and "1" on USB Phone, this number will be shown on the Skype window, then press the SEND key.
- ✚ For Skypeout
 - Press "00"+"country number"+"phone number", then press SEND key(☎);
- ✚ Adjust options (volume and ringer)
 - Double click the 🔊 on the taskbar, then you can adjust the volume and ringer

Install figure

